The Dream Thermostat Instruction Manual

Energex

Display.

Your Thermostat displays your current room temperature (Ambient)

*if you thermostat gets locked, simply press and hold the knob for 8 seconds and you will see the lock disappear

19°C

Energex

Temperature Control

- **To heat-** Move the knob to the right (the knob will turn red)

- **To cool-** Move the knob to the left (the knob will turn blue)

Thermsotat Lower Bar Menu
*press once to activate

- **FAN-** Once you activate the lower bar menu the "FAN" will be highlighted in yellow, simply press the knob, and you will see 2 or 3 options (depending on your system), navigate with the knob towards the desired option and just press once to activate it. (after pressing the desired option the thermostats will get back to the actual room temperature in 3 seconds).

- **OFF-**Press the knob once to activate the lower bar menu, then move the knob towards the "OFF" option (make sure it's highlighted in yellow), then simply press once. (to turn back the system simply press/move the knob)

- **F/C-**Press the knob once to activate the lower bar menu, then move the knob towards the "F/C" (if the thermostats show Fahrenheit the letter "F" will be highlighted in yellow, if the thermostats show Celsius the letter "C" will be highlighted in yellow) by simply pressing F/C it will change between the languages, once you decide which language is better for you, leave the knob and the lower bar menu will disappear.

19°C

FAN | OFF | F/C

Energex